

BEANAIR

BEANDEVICE® PROCESSSENSOR USER  
MANUAL  
AN-420 / AN-mV/AN-V & ~~X~~tender





"Rethinking sensing technology"

Document version:2.2

Document Type : User Manual

BeanDevice® User Manual –  
ProcessSensor product lines

### DOCUMENT

<b>Document number</b>		<b>Version</b>	2.3
<b>External Reference</b>		<b>Last Publication date</b>	22/12/2016
<b>Author</b>	Maxime Obraz.		
<b>Document code</b>		<b>Project Code</b>	
<b>Document Name</b>	BeanDevice® User Manual		

### VALIDATION

Function	Recipients	Validation	Information
<b>Writer</b>	Rasha Friji		
<b>Reader</b>	Maxime Obraztsov		X
<b>Approbation</b>	Mohamed-Yosri Jaouadi	X	

### DIFFUSION

Function	Recipients	Validation	Action
<b>Reader 1</b>	Philippe FROMON, Embedded software engineer	X	
<b>Reader 2</b>	Christophe DONTEGREUIL, Technical support engineer	X	

### Updates

Version	Date	Author	Evolution & Status
1.9	20/07/2012	Christophe Dontegreuil	BeanDevice® AN-XX Xtender added
2.0	25/06/2015	Maxime Obraztsov	TimeSync function added
2.1	21/03/2016	Rasha Friji	<ul style="list-style-type: none"> <li>Standalone option</li> <li>Battery level display</li> </ul>
2.2	21/04/2016	Rasha Friji	<ul style="list-style-type: none"> <li>Antenna specifications updated</li> <li>Further description about sensor wiring code</li> </ul>
2.3	22/12/2016	Salah Riahi	<ul style="list-style-type: none"> <li>Exporting a log file to Excel video added</li> </ul>



Please consider the environment before printing this document.



- 1. TECHNICAL SUPPORT ..... 9
- 1. VISUAL SYMBOLS DEFINITION ..... 10
- 2. ACRONYMS AND ABBREVIATIONS..... 11
- 3. RELATED DOCUMENTS & VIDEOS..... 12
  - 3.1 Applications & Technical Notes ..... 12
  - 3.2 Related videos..... 12
- 4. DOCUMENT ORGANISATION ..... 13
- 5. BEANDEVICE® PRODUCT OVERVIEW ..... 14
  - 5.1 Introduction to ProcessSensor product lines ..... 14
  - 5.2 Advantages of using the BeanDevice® AN-XX Xtender..... 16
  - 5.3 BeanDevice® Technical specifications ..... 16
    - 5.3.1 Common technical specifications ..... 16
    - 5.3.2 BeanDevice® AN-420 & AN-420 XTender ..... 18  
20
    - 5.3.3 BeanDevice AN-mV & AN-mV Xtender ..... 21
    - 5.3.4 BeanDevice® AN-V & AN-V Xtender ..... 23
  - 5.4 Technical specifications ..... 27
    - 5.4.1 Common Specifications ..... 27
    - 5.4.2 BeanDevice® AN-420 & AN-420 Xtender..... 29
  - 5.5 Product focus: BeanDevice® AN-mv/AN-V/AN-420 ..... 32
  - 5.6 Product FOCUS: BeanDevice® AN-420/AN-V/AN-mV Xtender..... 35
  - 5.7 Leds description ..... 38
  - 5.8 RF Antenna..... 38





*"Rethinking sensing technology"*

Document version:2.2

Document Type : User Manual

BeanDevice® User Manual –  
ProcessSensor product lines

- 5.8.1 Antenna diversity ..... 38
- 5.8.2 Antenna specifications..... 39
- 5.8.3 Mechanical specifications and dimensions ..... 39
- 5.8.4 Performances ..... 41
- 5.9 Sensor Interface ..... 43
  - 5.9.1 How to connect a sensor on your BeanDevice®? ..... 43
  - 5.9.2 Sensor power supply..... 45
  - 5.9.3 Sensor wiring code (General overview)..... 47
  - 5.9.4 Sensor wiring code (BeanDevice® AN-420) ..... 49
  - 5.9.5 Sensor wiring code (BeanDevice® AN-V & AN-mV) ..... 51
- 5.10 Mechanical drawing (BeanDevice® AN-XX) ..... 53
- 5.11 BeanDevice® AN-XX Power Supply ..... 54
  - 5.11.1 Lithium-ion Rechargeable battery ..... 54
  - 5.11.2 AC-To-DC power adapter ..... 54
  - 5.11.3 External Power supply wiring code (not available on the BeanDevice® AN-XX Xtender)  
55
- 5.12 BeanDevice® AN-XX Extender Power Supply ..... 56
  - 5.12.1 Primary Cell specifications ..... 56
  - 5.12.2 How to change the Primary cell on the BeanDevice® AN-XX Xtender ..... 57
- 6. DATA ACQUISITION MODE DESCRIPTION ..... 60
- 7. BEANDEVICE® PROCESSENSOR INSTALLATION GUIDELINES ..... 61
  - 7.1 Power Mode Management ..... 61
  - 7.2 BeanDevice® Network Association ..... 61
  - 7.3 Datalogger function ..... 61
  - 7.4 OTAC (Over-the-air-Configuration) process ..... 61
  - 7.5 Factory settings..... 62
- 8. BEANDEVICE® SUPERVISION FROM THE BEANSCAPE ..... 64
  - 8.1 Starting the BeanScape® ..... 64
  - 8.2 Displaying the BeanDevice® Informations ..... 65
    - 8.2.1 Frame: Identity..... 66
    - 8.2.2 Frame: Wireless Network Diagnostic..... 66
    - 8.2.3 Frame: Power supply diagnostic ..... 67
    - 8.2.4 Frame: System..... 69



- 8.2.5 Frame: BeanDevice® ..... 69
- 8.2.6 Frame: Product Version ..... 70
- 8.2.7 Frame: Actual Data Acquisition mode ..... 70
- 8.2.8 Frame: Battery/Primary Cell status ..... 71
- 8.3 BeanDevice® Configuration ..... 72
  - 8.3.1 Tab: Custom Display..... 73
  - 8.3.2 Tab: Notes ..... 74
  - 8.3.3 Tab : Data Acquisition configuration ..... 75
  - 8.3.4 Tab: Datalogger ..... 78
  - 8.3.5 Tab : System config. .... 80
  - 8.3.6 Tab : Power mode management ..... 82
- 8.4 Sensors configuration ..... 85
  - 8.4.1 Sensor profile ..... 86
  - 8.4.2 Sensor configuration & calibration ..... 87
  - 8.4.3 Graphical display ..... 93
- 8.5 Datalogger configuration ..... 96
- 8.6 Log file organization ..... 97
  - 8.6.1 Log File System Overview ..... 97
  - 8.6.2 Log file directory ..... 97
  - 8.6.3 Log Folder..... 99
  - 8.6.4 Log file size configuration ..... 100
  - 8.6.5 Log file generation ..... 101
  - 8.6.6 Cache Data Configuration (for Graph) ..... 101
  - 8.6.7 Log file related to data acquisition ..... 102
  - 8.6.8 Log file organization in” Streaming Packet” mode ..... 104
- 9. BEANDEVICE® MAINTENANCE & SUPERVISION (FOR EXPERIENCED USER)..... 109
  - 9.1 How to optimize the battery autonomy on your BeanDevice® ..... 109
  - 9.2 Over-the-air Configuration (OTAC) parameters backed up on Flash ..... 111
    - 9.2.1 Level 1: End-user OTAC parameters ..... 112
    - 9.2.2 Level 2: Sensor calibration parameters ..... 113
    - 9.2.3 Level 3: Network maintenance (only for expert in wireless sensor networks) ..... 113
    - 9.2.4 Level 4: Primary cell/Rechargeable battery calibration..... 114
  - 9.3 Network diagnostic from your BeanScope® software ..... 114
    - 9.3.1 Displaying Network information ..... 114
    - 9.3.2 Scrolling menu « BeanSensor » ..... 118





*"Rethinking sensing technology"*

Document version:2.2

Document Type : User Manual

BeanDevice® User Manual –  
ProcessSensor product lines

10. TROUBLESHOOTING ..... 122

11. INSTALLATION PROCEDURES ..... 124

    11.1 Sealing ..... 124

    11.2 Coexistence With others Frequencies at 2.4 GHz..... 124

    11.3 TempErature & Humidity ..... 124

    11.4 Reflections, Obstructions and Multipath..... 125

    11.5 shock & Vibration resistance ..... 126

    11.1 Antenna..... 126



**Table list**

**Table 1: RF specifications Table** .....16  
**Table 2 : Antenna specifications** .....39  
**Table 3: External sensor power supply specifications**.....45  
**Table 4: Primary cell specifications table** .....56  
**Table 5: Factory settings** .....62

**Figure List**

**Figure 1: Focus on BeanDevice® AN-V/AN-mV/AN-420** .....32  
**Figure 2: BeanDevice® AN-420/AN-V/AN-mV Xtender** .....35  
**Figure 3: Antenna Diversity present on the BeanDevice® AN-420/AN-V/AN-mV**.....39  
**Figure 4 : Antenna Mechanical drawing**.....40  
**Figure 5 : 3D Radiation pattern and antenna gain** .....41  
**Figure 6 : Radiation pattern** .....42  
**Figure 7: Sensor connection on the BeanDevice®**.....44  
**Figure 8: Sensor power supply**.....46  
**Figure 9: M12 socket location the BeanDevice®** .....47  
**Figure 10: M12 Socket - positioning notch**.....48  
**Figure 11: M12 socket Pin assignation** .....48  
**Figure 12 : M12 socket Wiring Code (BeanDevice® side)** .....49  
**Figure 13: M12-4pins Plug Wiring code (sensor side)**.....50  
**Figure 14: Wiring code (sensor side) – Analog unipolar** .....51  
**Figure 15: Wiring code (sensor side) – Analog bipolar** .....52  
**Figure 16: Mechanical Drawing** .....53  
**Figure 17 : External power supply M8-3Pin - BeanDevice® side** .....55  
**Figure 18 : External power supply wiring code (M8-3Pin Plug side)**.....56  
**Figure 19 : Power mode management** .....83



### *Disclaimer*

The information contained in this document is the proprietary information of Beanair.

The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of Beanair Ltd, is strictly prohibited.

Beanair makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, Beanair does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

Beanair disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

Beanair reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document.

Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © Beanair GmbH 2015



## 1. TECHNICAL SUPPORT

---

For general contact, technical support, to report documentation errors and to order manuals, contact **Beanair Technical Support Center** (BTSC) at:

[tech-support@Beanair.com](mailto:tech-support@Beanair.com)

For detailed information about where you can buy the Beanair equipment/software or for recommendations on accessories and components visit:

[www.Beanair.com](http://www.Beanair.com)

To register for product news and announcements or for product questions contact Beanair's Technical Support Center (BTSC).

Our aim is to make this user manual as helpful as possible. Please keep us informed of your comments and suggestions for improvements. Beanair appreciates feedback from the users.



## 1. VISUAL SYMBOLS DEFINITION

---

<i>Symbols</i>	<i>Definition</i>
	<b><u>Caution or Warning</u></b> – Alerts the user with important information about Beanair wireless sensor networks (WSN), if this information is not followed, the equipment /software may fail or malfunction.
	<b><u>Danger</u></b> – This information <b>MUST</b> be followed if not you may damage the equipment permanently or bodily injury may occur.
	<b><u>Tip or Information</u></b> – Provides advice and suggestions that may be useful when installing Beanair Wireless Sensor Networks.



## 2. ACRONYMS AND ABBREVIATIONS

---

<i>AES</i>	Advanced Encryption Standard
<i>CCA</i>	Clear Channel Assessment
<i>CSMA/CA</i>	Carrier Sense Multiple Access/Collision Avoidance
<i>GTS</i>	Guaranteed Time-Slot
<i>kSps</i>	Kilo samples per second
<i>LLC</i>	Logical Link Control
<i>LQI</i>	Link quality indicator
<i>LDCDA</i>	Low duty cycle data acquisition
<i>MAC</i>	Media Access Control
<i>PAN</i>	Personal Area Network
<i>PER</i>	Packet error rate
<i>RF</i>	Radio Frequency
<i>SD</i>	Secure Digital
<i>WSN</i>	Wireless sensor Network



### 3. RELATED DOCUMENTS & VIDEOS

---

In addition to this User manual, please consult the related application notes, technical notes and videos:

#### 3.1 APPLICATIONS & TECHNICAL NOTES

---



*Our latest applications and technical notes are available on the following link:*

[Click here](#)

#### 3.2 RELATED VIDEOS

---



[All the videos are available on our Youtube channel](#)



## 4. DOCUMENT ORGANISATION

---

This manual is organized in 7 chapters, as follows:

### BeanDevice® product overview

- Details the BeanDevice® product presentation

### Data acquisition mode description

- Details the data acquisition mode available on the BeanDevice®
- **Related Technical Note:** TN\_RF\_008 - "Data acquisition mode available on the BeanDevice®"

### BeanDevice® installation guidelines

- Details the installation guidelines of the BeanDevice®
- **Related Technical Note:** TN\_RF\_010 - "Beandevic® Power Management "
- **Related Technical Note:** TN\_RF\_007- "Beandevic® DataLogger user Guide"
- **Related Technical Note:** TN\_RF\_006- "Beandevic® wireless network association"

### BeanDevice® supervision from the Beanscape®

- Details the BeanDevice® supervision from the Beanscape®

### BeanDevice® maintenance (for experienced user)

- Details the BeanDevice® maintenance (for experienced user)

### Troubleshooting

- Frequently asked questions (FAQ)

### Installation procedures

- Details the installation procedures



## 5. BEANDEVICE® PRODUCT OVERVIEW



***It is highly recommended to read all the user manual related to Beanair software & equipment (BeanScope®, BeanGateway®, BeanDevice®) before getting start your BeanDevice®.***

### 5.1 INTRODUCTION TO PROCESSENSOR PRODUCT LINES

ProcessSensor product line comes with Wireless analog DAQ compatible with a large scale of analog sensors:

- Analog voltage  $\pm 5V$  and  $\pm 10V$
- Analog low voltage  $\pm 20mV$  compatible with strain gauge sensor
- Analog current loop 4-20 mA

It comes with advanced features:

- ✓ High measurement precision (less than  $\pm 0.08\%$  on the full scale)
- ✓ Providing power supply to external analog sensors (user configurable: 4.5V up to 20V)
- ✓ Back Up data acquisition on an internal flash memory (embedded Datalogger)
- ✓ Transmitting data by wireless
- ✓ Compatible with sleep or active power mode

BeanDevice® AN-420 & BeanDevice® AN-420 Xtender	Wireless system acquisition for analog 4-20 mA current loop measurement.
BeanDevice® AN-V & BeanDevice® AN-V Xtender	Wireless system acquisition for analog differential measurement $\pm 5$ volts or $\pm 10$ volts.
BeanDevice® AN-mV	Wireless system acquisition for analog differential measurement $\pm 20$ mV This product is dedicated to sensors integrating a Wheatstone bridge (strain gauge sensors, load cell sensors, pressure...).





*Industrial sensors commonly use a 4-20 mA DC signal. With this method, the sensor signal is conveyed as a current. Raw output of the sensor will either be 4 mA at the lowest or 20 mA at the highest. By examining the current between 4 and 20 mA an actual reading can be determined. For example, assume an air temperature sensor has a range of 0°C to 100°C. If the output from the temperature sensor is 4 mA, then the temperature is 0°C. If the output from the sensor is 20 mA, then the temperature is 100°C. Readings between 4 and 20 mA are linear and simple to determine.*

*One of the major advantages of using 4-20 mA sensors is the limited signal loss of these devices. By outputting a sensor signal in the form of current, electrically noisy areas do not have an effect on the sensor's readings. Furthermore, accuracy is not affected by changes in line and connection resistance, or by the addition of other loads in the circuit.*



## 5.2 ADVANTAGES OF USING THE BEANDEVICE® AN-XX XTENDER

The BeanDevice® AN-XX Xtender uses a Primary cell (5800 mAh) instead of a rechargeable battery (950mAh), it provides a better battery autonomy.

This product is ideal for telemetry applications on remote sites (Greenhouses, Water treatment plant, water intake...).

## 5.3 BEANDEVICE® TECHNICAL SPECIFICATIONS

### 5.3.1 Common technical specifications

#### 5.3.1.1 RF specifications

		RF Specifications
<b>Wireless Stack</b>	<b>Protocol</b>	IEEE 802.15.4 (2006 version)
<b>WSN Topology</b>		Point-to-Point / Star
<b>Encryption</b>		AES 128 bits (AES integrated coprocessor)
<b>Data rate</b>		250 Kbits/s
<b>RF Characteristics</b>		ISM 2.4GHz – 16 Channels. Antenna diversity architecture designed by Beanair®
<b>TX Power</b>		+0 dBm to +18 dBm
<b>Receiver Sensitivity</b>		-95,5 dBm to -104 dBm
<b>Maximum Range</b>	<b>Radio</b>	1 Km (L.O.S)
<b>Antenna</b>		Antenna diversity: 2 omnidirectional N-Type antenna with a gain of 2.2 dBi Degree of protection IP67

**Table 1: RF specifications Table**



5.3.1.2 Others specifications (BeanDevice® AN-XX only)

	Others specifications
<b>Embedded logger</b>	<ul style="list-style-type: none"> <li>• Storage Capacity: up to 1 000 000 measurements</li> <li>• Integrated real time clock</li> <li>• Write/read Cycle: 400 000</li> </ul>
<b>Integrated battery charger</b>	Integrated Lithium-ion battery charger with high precision battery monitoring: <ul style="list-style-type: none"> <li>• Overvoltage Protection, Overcurrent/Short-Circuit Protection, Under voltage Protection</li> <li>• Battery Temperature monitoring</li> <li>• Current accumulation measurement</li> </ul>
<b>Current consumption</b>	<ul style="list-style-type: none"> <li>• During data acquisition: 70mA to 130 mA (depends on external sensor power consumption)</li> <li>• During Radio transmission: 60 mA @ 0dBm</li> <li>• During sleeping: &lt; 45 uA</li> </ul>
<b>Operating Temperature</b>	-20 °C to +75 °C - Integrated temperature sensor (resolution 0.125°C)
<b>Enclosure</b>	Aluminium, Watertight IP65 – Fire Protection: ULV94/Getex Enclosure dimensions (without antenna) L x l x h : 146.05 mm x 65.5mm x 33.5 mm
<b>Shocks resistance</b>	10g during 50 ms
<b>Norms</b>	CE Labelling Directive R&TTE (Radio) ETSI EN 300 328 ROHS - Directive 2002/95/EC
<b>External power supply</b>	External power supply: +8v to +28v
<b>Rechargeable battery</b>	Lithium-Ion high density rechargeable battery capacity of 950 mAh
<b>Power-supply bloc (Option)</b>	Wall plug-in, Switch mode power Supply 12V @ 1,25A with sealed M8 Plug (IP67)
<b>Mechanical mounting (Option)</b>	DIN Rail mounting



### 5.3.2 BeanDevice® AN-420 & AN-420 XTender

#### 5.3.2.1 Product reference


Product reference	
BND-A420 -NCH -WP-BT	
<b>N- Number of data acquisition channels :</b> - 2 : 2 Channels - 4 : 4 Channels	<b>WP– Wireless Protocol</b> - IEEE : IEEE 802.15.4 (2006)
Example : BND-AN420 –4CH -IEEE BeanDevice® AN-420 with four channels , IEEE 802.15.4(2006) , Rechargeable battery	

#### 5.3.2.2 Analog data acquisition block specifications

Analog data acquisition block specifications	
Signal Conditioning	Analog current loop measurement
Number of channels	2 or 4 Channels
A/D Converter	16 bits - SAR Architecture (Successive Approximation Register) with temperature compensation
Measurement range	4-20 mA Current Loop measurement
Non-linearity error	± 0,5 LSB
Measurement accuracy	< 0,1% when the BeanDevice is connected to an external power supply < 0,08% when the BeanDevice operates on battery
Sensor Connector	M12-5Pins, degree of protection IP67



### 5.3.2.3 OTAC Parameter



The BeanScape® application allows the user to view all the data measurements transmitted by the **BeanDevice® AN-420**.

With the OTAC (Over-the-Air configuration) feature, the user can remotely configure the **BeanDevice® AN-420**

Several Data acquisition modes are available on the **BeanDevice® AN-420**:

- **Low Duty Cycle Data Acquisition mode (LDCDA):** the data acquisition is immediately transmitted by radio. The transmission frequency can be configured from 1s to 24h.
- **Survey Mode:** operates like the Alarm mode but the device sends frequently a beacon frame informing its current status.
- **Streaming Packet Mode:** All measured values are transmitted by packet within a continuous flow at 400 samples per second maximum
- **Streaming Mode:** all measured values are transmitted in real-time within a continuous flow at 100 samples per second maximum
- **Math Mode:** Values such as the mean value, maximum value, minimum value and standard deviation are calculated on sample time series and transmitted by radio .



	Over-the-air configuration (OTAC) parameters
Data Acquisition mode	<p><b>Low Duty Cycle Data Acquisition (LDCDA) Mode:</b> 1s to 24 hour</p> <p><b>Survey mode:</b> 1s to 24 hour</p> <p><b>Math Mode:</b> 400 SPS maximum</p> <p><b>Streaming Packet Mode:</b> 400 SPS maximum</p>
Sampling Rate (SPS = sample per second)	<p>Minimum: <b>1 SPS</b></p> <p>Maximum: <b>400 SPS</b> maximum on each channel</p>
Alarm Threshold	2 high levels alarms & 2 low levels alarms
Sensor power supply	<b>4.5 to 20 Volts</b>
Power Mode	Sleeping, Sleeping with Network Listening & Active
TX Power	-7 dBm / -1 dBm / 5 dBm / 11 dBm / 15 dBm / 18 dBm



### 5.3.3 BeanDevice AN-mV & AN-mV Xtender

#### 5.3.3.1 Product reference


Product reference	
BND-ANmV –NCH –MR-WP-BB	
<b>N- Number of data acquisition channels :</b> - <b>2</b> : 2 Channels	<b>MR-measurement range</b> - <b>20</b> : ±20mV measurement range - <b>40</b> : ±40mV measurement range
<b>WP– Wireless Protocol</b> - <b>IEEE</b> : IEEE 802.15.4 (2006)	<b>BB– Battery Type</b> - <b>RB</b> : rechargeable battery
Example : BND-ANMV –2CH –20-IEEE-RB BeanDevice® AN-mV with two channels , measurement range ± 20mV IEEE 802.15.4(2006) , Rechargeable battery	

#### 5.3.3.2 Analog data acquisition block specifications

Analog data acquisition block specifications	
<b>Signal Conditioning</b>	Analog low voltage mV <b>with voltage-compensated measurement</b>
<b>Number of channels</b>	2 Channels
<b>A/D Converter</b>	16 bits - SAR Architecture (Successive Approximation Register) with temperature compensation
<b>Measurement range</b>	±20 mV (bipolar) or 0-40 mV (unipolar) ±-40 mV (bipolar) or 0-80mV (unipolar)
<b>Non-linearity error</b>	± 0,5 LSB
<b>Measurement accuracy</b>	< 0,2% when the BeanDevice is connected to an external power supply < 0,1% when the BeanDevice operates on battery
<b>Sensor Connector</b>	M12-5Pins, degree of protection IP67



### 5.3.3.3 OTAC Parameter



The BeanScape® application allows the user to view all the data transmitted by the **BeanDevice® AN-mV**.

With the OTAC (Over-the-Air configuration) feature, the user can remotely configure the **BeanDevice® AN-mV**

Several Data acquisition modes are available on the BeanDevice® AN-mV:

- **Low Duty Cycle Data Acquisition mode (LDCDA):** the data acquisition is immediately transmitted by radio. The transmission frequency can be configured from 1s to 24h.
- **Alarm Mode:** the measured value is transmitted by radio whenever the threshold level is reached (determined by the user, 4 alarm threshold levels High/Low).
- **Survey Mode:** operates like the Alarm Mode but the device sends frequently a beacon frame informing its current status.
- **Streaming Packet Mode:** All measured values are transmitted by packet within a continuous flow at 400 Hz maximum
- **Streaming Mode:** all measured values are transmitted in real-time within a continuous flow at 100 Hz maximum
- **Math Mode:** Values such as the mean value, maximum value, minimum value and standard deviation are calculated on sample time series and transmitted by radio.



Over-the-air configuration (OTAC) parameters	
Data Acquisition mode	<p><b>Low Duty Cycle Data Acquisition (LDCDA) Mode:</b> 1s to 24 hour</p> <p><b>Survey mode:</b> 1s to 24 hour</p> <p><b>Math Mode:</b> 400 SPS maximum</p> <p><b>Streaming Packet Mode:</b> 400 SPS maximum</p>
Sampling Rate (SPS = sample per second)	<p>Minimum: <b>1 SPS</b></p> <p>Maximum: <b>400 SPS</b> maximum on each channel</p>
Alarm Threshold	2 high levels alarms & 2 low levels alarms
Sensor power supply	<b>4.5 to 20 Volts</b>
Power Mode	Sleeping, Sleeping with Network Listening & Active
TX Power	-7 dBm / -1 dBm / 5 dBm / 11 dBm / 15 dBm / 18 dBm

### 5.3.4 BeanDevice® AN-V & AN-V Xtender

#### 5.3.4.1 Product reference

Product reference	
BND-ANV – <b>NCH</b> – <b>MR-WP-BT</b>	
<p><b>N- Number of data acquisition channels :</b></p> <ul style="list-style-type: none"> <li>- <b>2</b> : 2 Channels</li> <li>- <b>4</b> : 4 Channels</li> </ul>	<p><b>MR-Measurement Range</b></p> <ul style="list-style-type: none"> <li>- <b>5</b> : ±5V measurement range</li> <li>- <b>10</b>: ±10V measurement range</li> </ul>
<p><b>WP- Wireless Protocol</b></p> <ul style="list-style-type: none"> <li>- <b>IEEE</b> : IEEE 802.15.4 (2006)</li> </ul>	<p><b>BT- Battery Type</b></p> <ul style="list-style-type: none"> <li>- <b>RB</b>: rechargeable battery</li> </ul>
<p><b>Example 1</b> : BND-ANV –<b>2CH</b> –<b>5-IEEE-RB</b>            BeanDevice® AN-V with two channels, measurement range: ±5V, IEEE 802.15.4(2006), Rechargeable battery</p> <p><b>Example 2</b>: BND-ANV –<b>4CH</b> –<b>10-IEEE-RB</b>            BeanDevice® AN-V with four channels, measurement range: ±10V, IEEE 802.15.4(2006), Rechargeable battery</p>	




5.3.4.2 Analog data acquisition block specifications

	Analog data acquisition block specifications
<b>Signal Conditioning</b>	Analog voltage measurement
<b>Number of channels</b>	4 Channels
<b>A/D Converter</b>	16 bits - SAR Architecture (Successive Approximation Register) with temperature compensation
<b>Measurement range</b> (analog polarity is configurable from the BeanScape®)	RBND-ANV –NCH –5-IEEE-BT: ±5V (bipolar) or 0-10 V (unipolar)
	BND-ANV –NCH –10-IEEE-BT: ±10V (bipolar) or 0-20 V (unipolar)
<b>Non-linearity error</b>	± 0,5 LSB
<b>Measurement accuracy</b>	< 0,1% when the BeanDevice is connected to an external power supply < 0,08% when the BeanDevice operates on battery
<b>Sensor Connector</b>	M12-5Pins, degree of protection IP67



### 5.3.4.3 OTAC Parameter



The BeanScope® application allows the user to view all the data measurements transmitted by the **BeanDevice® AN-V**.

With the OTAC (Over-the-Air configuration) feature, the user can remotely configure the **BeanDevice® AN-V**

Several Data acquisition modes are available on the **BeanDevice® AN-V**:

- **Low Duty Cycle Data Acquisition mode (LDCDA):** the data acquisition is immediately transmitted by radio. The transmission frequency can be configured from 1s to 24h.
- **Alarm Mode:** the measured value is transmitted by radio whenever an alarm threshold (fixed by the user) is detected (4 alarms threshold levels High/Low).
- **Survey Mode:** operates like the Alarm mode but the device sends frequently a beacon frame informing its current status.
- **Streaming Packet Mode:** All measured values are transmitted by packet within a continuous flow at 400 samples per second maximum
- **Math Mode:** Values such as the mean value, maximum value, minimum value and standard deviation are calculated on sample time series and transmitted by radio.



Over-the-air configuration (OTAC) parameters	
<b>Data Acquisition mode</b>	<p><b>Low Duty Cycle Data Acquisition (LDCDA) Mode:</b> 1s to 24 hour</p> <p><b>Survey mode:</b> 1s to 24 hour</p> <p><b>Math Mode :</b> 400 SPS maximum</p> <p><b>Streaming Packet Mode:</b> 400 SPS maximum</p>
<b>Sampling Rate</b> (SPS = sample per second)	<p>Minimum: <b>1 SPS</b></p> <p>Maximum: <b>400 SPS</b> maximum on each channel</p>
<b>Alarm Threshold</b>	2 high levels alarms & 2 low levels alarms
<b>Sensor power supply</b>	<b>4.5 to 20 Volts</b>
<b>Power Mode</b>	Sleeping, Sleeping with Network Listening & Active
<b>TX Power</b>	-7 dBm / -1 dBm / 5 dBm / 11 dBm / 15 dBm / 18 dBm



## 5.4 TECHNICAL SPECIFICATIONS

### 5.4.1 Common Specifications

#### 5.4.1.1 RF specifications

	RF Specifications
<b>Wireless Protocol Stack</b>	IEEE 802.15.4 (2006 version)
<b>WSN Topology</b>	Point-to-Point / Star
<b>Encryption</b>	AES 128 bits (AES integrated coprocessor)
<b>Data rate</b>	250 Kbits/s
<b>RF Characteristics</b>	ISM 2.4GHz – 16 Channels. Antenna diversity architecture designed by Beanair®
<b>TX Power</b>	+0 dBm to +18 dBm
<b>Receiver Sensitivity</b>	-95,5 dBm to -104 dBm
<b>Maximum Radio Range</b>	1 Km (L.O.S)
<b>Antenna</b>	Antenna diversity : 2 omnidirectional N-Type antenna with a gain of 2.2 dBi Degree of protection IP67

#### 5.4.1.2 Other specifications

	Others specifications
<b>Embedded logger</b>	<ul style="list-style-type: none"> <li>• Storage Capacity : up to 1 000 000 measurements</li> <li>• Integrated real time clock</li> <li>• Write/read Cycle: 400 000</li> </ul>
<b>Integrated battery charger</b>	Integrated Lithium-ion battery charger with high precision battery monitoring : <ul style="list-style-type: none"> <li>• Overvoltage Protection, Overcurrent/Short-Circuit Protection, Undervoltage Protection</li> <li>• Battery Temperature monitoring</li> </ul>



	<ul style="list-style-type: none"> <li>• Current accumulation measurement</li> </ul>
<b>Current consumption</b>	<ul style="list-style-type: none"> <li>• During data acquisition : 70mA to 130 mA (depends on external sensor power consumption)</li> <li>• During Radio transmission : 60 mA @ 0dBm</li> <li>• During sleeping: &lt; 45 uA</li> </ul>
<b>Operating Temperature</b>	-20 °C to +75 °C - Integrated temperature sensor (resolution 0.125°C)
<b>Enclosure</b>	Aluminium, Watertight IP65 – Fire Protection : ULV94/Getex Enclosure dimensions (without antenna ) L x l x h : 146.05 mm x 65.5mm x 33.5 mm
<b>Shocks resistance</b>	10g during 50 ms
<b>Norms</b>	CE Labelling Directive R&TTE (Radio) ETSI EN 300 328 ROHS - Directive 2002/95/EC
<b>External power supply</b>	External power supply : +8v to +28v
<b>Rechargeable battery</b>	Lithium-Ion high density rechargeable battery capacity of 950 mAh
<b>Power-supply bloc (Option)</b>	Wall plug-in, Switchmode power Supply 12V @ 1,25A with sealed M8 Plug (IP67)
<b>Mechanical mounting (Option)</b>	DIN Rail mounting



## 5.4.2 BeanDevice® AN-420 & AN-420 Xtender

### 5.4.2.1 Product reference


Product reference	
BND-A420 - <i>NCH</i> - <i>WP-BT</i>	
<b><i>N- Number of data acquisition channels :</i></b> - <b>2</b> : 2 Channels - <b>4</b> : 4 Channels	<b><i>WP– Wireless Protocol</i></b> - <b>IEEE</b> : IEEE 802.15.4 (2006)
Example: BND-AN420 – <b>4CH</b> - <b>IEEE</b> <b>BeanDevice® AN-420 with four channels , IEEE 802.15.4(2006) , Rechargeable battery</b>	

### 5.4.2.2 Analog Data Acquisition specifications

BeanDevice® AN-420- analog data acquisition specifications	
<b>Signal Conditioning</b>	Analog current loop measurement
<b>Number of channels</b>	2 or 4 Channels
<b>A/D Converter</b>	16 bits - SAR Architecture (Successive Approximation Register) with temperature compensation
<b>Measurement range</b>	4-20 mA Current Loop measurement
<b>Non-linearity error</b>	± 0,5 LSB
<b>Measurement accuracy</b>	< 0,1% when the BeanDevice is connected to an external power supply < 0,08% when the BeanDevice operates on battery
<b>Sensor Connector</b>	M12-5Pins, degree of protection IP67



### 5.4.2.3 OTAC parameters



The BeanScape® application allows the user to view all the data measurements transmitted by the **BeanDevice® AN-420**.

With the OTAC (Over-the-Air configuration) feature, the user can remotely configure the **BeanDevice® AN-420**

Several Data acquisition modes are available on the **BeanDevice® AN-420**:

- **Low Duty Cycle Data Acquisition mode (LDCDA)**: the data acquisition is immediately transmitted by radio. The transmission frequency can be configured from 1s to 24h.
- **Survey Mode**: operates like the Alarm mode but the device sends frequently a beacon frame informing its current status.
- **Streaming Packet Mode**: All measured values are transmitted by packet within a continuous flow at 400 samples per second maximum
- **Math Mode**: Values such as the mean value, maximum value, minimum value and standard deviation are calculated on sample time series and transmitted by radio .



Over-the-air configuration (OTAC) parameters	
Data Acquisition mode	<p><b>Low Duty Cycle Data Acquisition (LDCDA) Mode:</b> 1s to 24 hour</p> <p><b>Survey mode:</b> 1s to 24 hour</p> <p><b>Math Mode:</b> 400 SPS maximum</p> <p><b>Streaming Packet Mode:</b> 400 SPS maximum</p>
Sampling Rate (SPS = sample per second)	<p>Minimum: <b>1 SPS</b></p> <p>Maximum: <b>400 SPS</b> maximum on each channel</p>
Alarm Threshold	2 high levels alarms & 2 low levels alarms
Sensor power supply	<b>4.5 to 20 Volts</b>
Power Mode	Sleeping, Sleeping with Network Listening & Active
TX Power	-7 dBm / -1 dBm / 5 dBm / 11 dBm / 15 dBm / 18 dBm



### 5.5 PRODUCT FOCUS: BEANDEVICE® AN-MV/AN-V/AN-420




Figure 1: Focus on BeanDevice® AN-V/AN-mV/AN-420



Number	Function	Description
	<p><b>M8-3 Contacts Socket for external power supply</b></p> 	<p><b>DC 8-28 volts</b> power supply</p> <p>The socket sealing is assured with a screw cap</p>  <p><b>Don't forget to protect the M8-3contacts socket with a screw cap. You will lose the tightness of your device if you do not close properly.</b></p>
	<p><b>Radio antenna</b></p>	<p>2x N-Type Radio antenna antenna , waterproof IP67</p>  <p><b>Do not try to change or modify the antenna, you will damage your BeanDevice®.</b></p>
	<p><b>ON/OFF push button</b></p>	<p>Allows to power up/power off the BeanDevice®</p> <p><b>ON : button pushed</b></p> <p><b>OFF : button not pushed</b></p>  <p><b>Wait for a minimum of 5 seconds before your power-up the BeanDevice®. The BeanDevice® integrates an energy tank allowing a backup of the WSN context before powering OFF.</b></p>
	<p><b>BeanDevice® Activity /Failure led</b></p>	<p>Bi-color <b>GREEN / RED Led</b></p> <p>Cf. Table for led description</p>
	<p><b>M12-5 Pins female socket for sensor interface</b></p>	<p>This socket is compatible with a M12-5 Pins A-Coding male plug.</p>
	<p><b>BeanDevice® product version label</b></p>	<p>Three label version are available :</p> <p><b>AN-420</b> : 4-20 mA current loop measurement</p> <p><b>AN-V</b> : +/-5 volts or +/-10 volts analog measurement</p> <p><b>AN-mV</b> : +/- 20 mV or +/-40 mV analog low voltage measurement</p>



	<p><b>Network context push button</b></p>	<p>To restore default/factory parameters, you must perform a <b>Network context deletion</b>. Push on the push-button ("Network") for more than 2 seconds.</p>
	<p><b>Eyelet for wall mounting</b></p>	<p>The BeanDevice® is provided with a wall mounting kit.</p>
	<p><b>M12 sensor cap</b></p>	<p>M12 sensor cap</p>  <p><b>Don't forget to protect the M12 contacts socket with a screw cap. You will lose the tightness of your device if you do not close properly.</b></p>
	<p><b>MAC ID Label</b></p>	<p>Unique identifier assigned to the BeanDevice® (64-bytes)</p>  <p><b>Every wireless network product which is based on the IEEE 802.15.4 standard must have a 64-bit MAC address that allows unique identification of the device within a global network.</b></p>



### 5.6 PRODUCT FOCUS: BEANDEVICE® AN-420/AN-V/AN-MV XTENDER



Figure 2: BeanDevice® AN-420/AN-V/AN-mV Xtender



Number	Function	Description
1	<b>Watertight battery holder</b>	DC 9-24 volts power supply The socket sealing is assured with a screw cap.  <b>Don't forget to protect the M8-3contacts socket with a screw cap.</b>
2	<b>Radio antenna</b>	2x N-Type Radio antenna Antenna , waterproof IP67  <b>Do not try to change or modify the antenna, you will damage your BeanDevice®.</b>
3	<b>ON/OFF push button</b>	Allows to power up/power off the BeanDevice® <b>ON : button pushed</b> <b>OFF : button not pushed</b>  <b>Wait for a minimum of 5 seconds before your power-up the BeanDevice®. The BeanDevice® integrates an energy tank allowing a backup of the WSN context before powering OFF.</b>
4	<b>BeanDevice® Activity /Failure led</b>	Bi-color <b>GREEN / RED Led</b> Cf. Table for led description
5	<b>M12-5 Pins female socket for sensor interface</b>	This socket is compatible with a M12-5 Pins A-Coding male plug.
6	<b>BeanDevice® product version label</b>	Three label version are available : <b>AN-420</b> : 4-20 mA current loop measurement <b>AN-V</b> : +/-5 volts or +/-10 volts analog measurement <b>AN-mV</b> : +/- 20 mV or +/-40 mV analog low voltage measurement



	<p><b>Network context push button</b></p>	<p>To restore default/factory parameters, you must perform a <b>Network context deletion</b>. Push on the push-button ("Network") for more than 2 seconds.</p>
	<p><b>Holes for wall mounting</b></p>	<p>The BeanDevice® is provided with a wall mounting kit.</p>
	<p><b>M12 sensor cap</b></p>	<p>M12 sensor cap</p>  <p><b>Don't forget to protect the M12 contacts socket with a screw cap. You will lose the tightness of your device if you do not close properly.</b></p>
	<p><b>MAC ID Label</b></p>	<p>Unique identifier assigned to the BeanDevice® (64-bytes)</p>  <p><b>Every wireless network product which is based on the IEEE 802.15.4 standard must have a 64-bit MAC address that allows unique identification of the device within a global network.</b></p>



**Recommendations:**

- ✓ **Use only accessories supplied by Beanair (batteries, power supply unit, and antenna). Use of other materials may damage the BeanDevice®;**
- ✓ **Only Beanair is qualified to make changes on the BeanDevice®;**
- ✓ **Don't try to remove the label on the product; it contains important information such as the MAC address or sensor measurement range**



## 5.7 LEDS DESCRIPTION

Operating status	Led Activity Failure
The BeanDevice® is power off & external power supply is connected.	LED OFF
The BeanDevice® is power down with no external power supply connected	LED OFF
The BeanDevice® is power on with wireless TX/RX activity	Green Led: Wireless Network Activity Red Led : Wireless transmission failure
The BeanDevice® is power on	Green led toggling
The BeanDevice® is power off (was power on before)	RED LED ON during 2s

## 5.8 RF ANTENNA

### 5.8.1 Antenna diversity

Antenna diversity is a technique that maximizes the performance of an antenna system. It allows the radio to switch between two antennas that have very low correlation between their received signals. Typically, this is achieved by spacing two antennas around 0.25 wavelengths apart or by using two orthogonal polarizations. So, if a packet is transmitted and no acknowledgement is received, the radio system can switch to the other antenna for the retry, with a different probability of success.



Figure 3: Antenna Diversity present on the BeanDevice® AN-420/AN-V/AN-mV

5.8.2 Antenna specifications

Specifications	
Antenna Gain	2.2 dBi
Frequency	2400-2485 MHz
Bandwidth	83,5 MHz
Connector	N-Type (male)
VSWR	<2.5:1
Polarisation	Verticale
Nominal impedance	50 Ohm
Weight	50g
Dimensions	length 154 mm
Material	TPE
Operating temperature	-40°C to 85°C




Table 2 : Antenna specifications

5.8.3 Mechanical specifications and dimensions

Material:	TPE
Max. dimensions:	10mm x 148mm (D x L)
Weight:	13 g
Color:	Black



**Figure 4 : Antenna Mechanical drawing**

### 5.8.4 Performances

Freq = 2.4437GHz    Az= 45    EL= 45






Figure 5 : 3D Radiation pattern and antenna gain





**Figure 6 : Radiation pattern**



## 5.9 SENSOR INTERFACE

### 5.9.1 How to connect a sensor on your BeanDevice®?

Several types of sensor can be plugged on your BeanDevice®:

- ✓ Current loop 4-20 mA
- ✓ Analog low voltage measurement  $\pm 20$  mV
- ✓ Analog differential measurement  $\pm 10$  V

Connecting a sensor is very easy but it requests to follow up several steps:

**Step 1:** Access the configuration tab for the selected sensor channel.

- Mount the M12 Plug on your sensor . Follow the wiring code available on this document;
- Don't plug your sensor on your BeanDevice® AN-XX;
- From your BeanScape® software, click on the sensor profile associated to your BeanDevice®

**Step 2:** Configure the sensor power supply

- Enter the value of your sensor power supply;
- A message appears on the screen, left click on "OK" to confirm.


**Step 3:** Connect your sensor on the BeanDevice

- Plug your sensor on your BeanDevice® AN-XX, an otch on the M12 connector allows a single way connection;
- Rotate the dial clockwise until fully tightened (do not overdo the rotating ring)
- You can start the calibration of your sensor from the BeanScape®;



*Sensors are not provided with the BeanDevice® AN-XX series*





*Figure 7: Sensor connection on the BeanDevice®*



### 5.9.2 Sensor power supply

The BeanDevice® AN-XX series can supply power to your external sensor. You can easily configure your sensor voltage from the BeanScape®.

The following table presents technical specifications:

<b>Technical specifications</b>		
<b>Voltage range</b>		4.5-20Volts DC (configurable from the BeanScape®)
<b>Voltage accuracy</b>		0.2%
<b>Maximum current delivered</b>		100 mA
<b>Maximum power delivered to the sensors</b>		1.5W
<b>Pre-process (time required to stabilize the measurement signal)</b>	<b>Max &amp; Min during</b>	<b>Configurable from the BeanScape® software:</b> 10 ms minimum 10000 ms maximum
	<b>Resolution</b>	20 ms


**Table 3:** External sensor power supply specifications

In order to optimize the low consumption on the BeanDevice®, the power supply provided to the sensor operates in switching mode:

- ✓ Before performing a measurement, the sensor is powered by the BeanDevice®. The pretreatment time is fixed by the end-user, it will reflect the time needed to stabilize the measurement signal after the sensor power-up;
- ✓ When all the measurement are done, the sensor is immediately power down;
- ✓ This cycle is repeated each time a data acquisition or a stream of data acquisition must be made;

**Example: Sensor power supply is settled at 10 volts with 400 ms pre-process time**





*Figure 8: Sensor power supply*



- ✓ Choose a sensor that requires a power supply having a pre-process duration as low as possible, otherwise you will decrease the BeanDevice® battery autonomy.
- ✓ Some sensors require a very long pre-process duration (1-2 minutes) and some others sensors will work with a lot of current consumption. In this case we advise you to power up the sensor with an external power source.
- ✓ If your pre-process period is higher than your data acquisition cycle, it will be automatically adjusted by the BeanDevice®.



**Don't forget to pre-configure the supply voltage and the pre-process duration of your sensor before connecting it. By configuring wrongly, you risk to damage your sensor.**



### 5.9.3 Sensor wiring code (General overview)

---



*Figure 9: M12 socket location the BeanDevice®*



Sensor channel label



Positioning notch

Figure 10: M12 Socket - positioning notch





Figure 11: M12 socket Pin assignation

M12-4Pins A-coding should be used



5.9.4 Sensor wiring code (BeanDevice® AN-420)

**M12 Socket Wiring code (BeanDevice® AN-420 side )**



**Caption :**

**PIN1 (Pwr+ ):** Sensor power supply

**PIN4 (SI):** signal input

**PIN2 :** Not used

**PIN3 (Gnd):** Electrical Ground

*Figure 12 : M12 socket Wiring Code (BeanDevice® side)*




**Caption :**

**PIN1 (Pwr+ ):** Sensor power supply

**PIN4 (SI):** signal input

**PIN2 :** Not used, must be connected to **Gnd**

**PIN3 (Gnd):** Electrical Ground



**Figure 13: M12-4pins Plug Wiring code (sensor side)**

**Instructions for connecting a 2-wire sensor:**

- ✓ Connect the sensor wire "Loop Supply" to **PIN1 (Pwr+)**
- ✓ Connect the sensor wire "Current output" 4-20mA to **PIN4(SI)**
- ✓ Use a jumper cable to connect **PIN3(Gnd)** to **PIN2**



### 5.9.5 Sensor wiring code (BeanDevice® AN-V & AN-mV)

## Wiring code (sensor side) Sensor with analog unipolar output




Figure 14: Wiring code (sensor side) – Analog unipolar



**Wiring code (sensor side)**  
**Sensor with analog bipolar output**


**Caption :****PIN1 (Pwr+ ):** Sensor power supply**PIN4 (Sens+):** Sensor signal + input**PIN2 (Sens-):** Sensor signal - input**PIN3 (Gnd):** Electrical Ground

Figure 15: Wiring code (sensor side) – Analog bipolar





✓ *If you use a unipolar analog sensor, Sens- pin must be connected to the electrical ground*



*You can damage your sensor and/or your BeanDevice® if you don't respect the wiring code.*

## 5.10 MECHANICAL DRAWING (BEANDEVICE® AN-XX)




Figure 16: Mechanical Drawing



## 5.11 BEANDEVICE® AN-XX POWER SUPPLY

### 5.11.1 Lithium-ion Rechargeable battery

The BeanDevice® from ProcessSensor product lines integrates a Lithium-Ion rechargeable battery:

Battery Capacity	Nominal Voltage	Charge/Discharge cycle
950 mAh	4,2V	300 cycles



*The rechargeable battery can be used as an UPS (uninterruptible power supply) battery on your BeanDevice®. It provides an emergency power when the input power source, typically the utility mains, fails.*



*Do not try to change the battery. You will void the guarantee of the product.*

### 5.11.2 AC-To-DC power adapter

The BeanDevice® can also be powered by an AC-to-DC adapter **8-28Volts**. The power adapter can be used for recharging Lithium-Ion battery or to power supply continuously the BeanDevice®. A M8-3Pins standard plug is used for connecting the power adapter to the BeanDevice®. If battery charge is very low, connect the power adapter in order to recharge your internal battery.





**Only the M8 plug is fully sealed, the power adapter is not sealed.**


### 5.11.3 External Power supply wiring code (not available on the BeanDevice® AN-XX Xtender)

Caption:

**PIN3 (Pwr+)** : power supply 8-28 V DC

**PIN1 (Gnd)** : electrical ground


#### External power supply wiring code (M8-3Pins Socket)



**Figure 17 : External power supply M8-3Pin - BeanDevice® side**



**External power supply wiring code**



**Caption:**  
**Pwr+** : Power supply 8-28V DC  
**Gnd** : Ground

**Figure 18 : External power supply wiring code (M8-3Pin Plug side)**

**5.12 BEANDEVICE® AN-XX EXTENDER POWER SUPPLY**

**5.12.1 Primary Cell specifications**

The BeanDevice® AN-XX Xtender integrates a Primary lithium-thionyl chloride cell (**Li-SoCl2**).

Primary Cell Capacity	Size	Nominal Voltage	Operating temperature range	Maximum recommended continuous current	Pulse Capability
6500 mAh	C-size spiral cell	3,6 V	- 40°C/+ 85°C	1A	1.5 to 2A during 0.1s

**Table 4: Primary cell specifications table**





- ***A Primary Cell is not a rechargeable battery; do not try to recharge it. You will damage your primary cell and your BeanDevice®***
- ***Do not use a primary cell with a Pulse Capability less than 1A. If you use an energy greedy sensor, your BeanDevice® will not be able to power supply correctly the sensor.***

We recommend you the following primary cell provider:

<i>Provider</i>	<i>Model</i>
<i>SAFT</i>	<i>LSH14</i>
<i>Europa Batteries</i>	<i>ER26500M</i>
<i>EVE</i>	
<i>Able Battery</i>	
<i>EEMB</i>	

### 5.12.2 How to change the Primary cell on the BeanDevice® AN-XX Xtender

Step 1 :  
Open The  
screw cap

- ***Open the screw cap***
- ***The primary cell is inside the battery holder***





Step 2 :  
Change the  
primary Cell

- **Change the primary cell**
- **Check the battery polarity: pole + is on the screw cap side;**

*Gasket*



*Pole +*



*Pole +*



Step 2 : Close  
the screw cap

- **Close properly the screw cap**
- **Don't forget the Gasket, otherwise you will loose the Beandevise sealing ;**



*Do not invert the battery polarity, your BeanDevice® will not work.*



## 6. DATA ACQUISITION MODE DESCRIPTION

---



Please read the technical note [TN RF 008 – “Data acquisition modes available on the BeanDevice®”](#)



## 7. BEANDEVICE® PROCESSENSOR INSTALLATION GUIDELINES

---

### 7.1 POWER MODE MANAGEMENT

---



Please read the technical note [TN RF 010 – « BeanDevice® Power Management »](#)

### 7.2 BEANDEVICE® NETWORK ASSOCIATION

---



Please read the technical note [TN RF 006 – “WSN Association process”](#)

### 7.3 DATALOGGER FUNCTION

---



Please read the technical note [TN RF 007 – “BeanDevice® Datalogger User Guide ”](#)

### 7.4 OTAC (OVER-THE-AIR-CONFIGURATION) PROCESS

---



Please read the technical note [TN RF 010 – « BeanDevice® Power Management »](#)



## 7.5 FACTORY SETTINGS

If desired, the user can restore factory settings on the BeanDevice® with the following default parameters:

Parameter	BeanDevice® version		
	AN-420	AN-V	AN-mV
Power Mode	Active	Active	Active
Data Acquisition duty cycle	10s	10s	10s
Acquisition duration time	OK	OK	OK
Sampling rate	OK	OK	OK
Data Acquisition mode	LowDutyCycle	LowDutyCycle	LowDutyCycle
TX Power	+18dBm	+18dBm	+18dBm
Alarms Threshold	H1 :20 H2 :20 S2 :4 S1 :4	H1 :10 H2 :10 S2 :0 S1 :0	H1 :20 H2 :20 S2 :0 S1 :0
Pre-process duration time	30 ms	30 ms	30 ms
Sensor polarity	N.A.	Unipolar	Unipolar

Table 5: Factory settings



To restore these default parameters, you must perform a **Network context deletion**. Push on the push-button ("Network") for more than 2 seconds.



*If you fix the TX power at its minimum value (-7dBm), and the wireless range is more than 5m, you will lose the radio signal. To find a configuration with a maximum RF: by pressing the Network Context button, you can reset to factory settings (default RF power is fixed at its maximum: 18 dBm)*



## 8. BEANDEVICE® SUPERVISION FROM THE BEANSCAPE





Don't hesitate to read the BeanScape® user manual for further information about the BeanScape®

### 8.1 STARTING THE BEANSCAPE®

BeanScape® is a supervision software monitor fully dedicated to Beanair WSN (Wireless Sensor Networks):



1. Start the BeanScape® by double-clicking on the BeanScape® icon
2. Click on the button « start » 
3. All the BeanDevice® connected to the WSN will appear on your left window
4. Select the BeanDevice® you want to configure. You can configure your BeanDevice® and its attached sensors.




BeanDevice® profile

Sensor channel

**The User interface is organized as follow:**

- Green on black background are displaying information




- Black on white background are customizable field;



You can configure your BeanDevice® from the page "**BeanDevice® System Profile**". This page is composed of two parts:

- ✓ BeanDevice® information display;
- ✓ BeanDevice® configuration;



**BeanDevice® System Profile**

*This part consists of a set of frames, with visualization field*


**BeanDevice® configuration frame is composed of several tabs**

## 8.2 DISPLAYING THE BEANDEVICE® INFORMATIONS

You will find below a description of the data information fields making up for each frame.



### 8.2.1 Frame: Identity



**MAC Address (encoded on 64-bits):** The Media Access Control address is a unique identifier assigned

**PAN Address (encoded on 16-bits):** Personal Area

**Network Address on 16-bits:** This address is allocated by the


**BeanDevice® Label:** By default the MAC address is Registered as a Label. This label can be changed by the user.



#### How PAN ID is assigned?

The BeanGateway® starts the WSN, assigning a PAN ID (Personal Area Network identifier) to the network. The PAN ID is pre-determined and cannot be modified. If you use several WSN, before deploying your BeanDevice® check to which WSN is assigned your BeanDevice®.

### 8.2.2 Frame: Wireless Network Diagnostic



**Link quality indicator of the BeanDevice® (0 to 255)**

**Global Packet error rate (PER) :** represents the PER on a


**Local Packet error rate (PER):** represents the PER between parent and child nodes.

$PER = \text{Number of lost packet} / \text{Total of packet transmitted}$



Number of bars	Color	Link quality indicator
5 to 6 bars	Green	Very good
4 bars	Green	Good
3 bars	Orange	medium
1 to 2 bars	Red	bad

### 8.2.3 Frame: Power supply diagnostic



Internal temperature of the BeanDevice® with a resolution of 0,125°C

Power supply Status: Main or Battery

This colored led indicates the BeanDevice power mode status. See below for more

Battery voltage in Volts

Battery level: three values: Good, medium, low



The BeanDevice® incorporates an internal temperature sensor dedicated to the following tasks:

- Battery temperature monitoring during charging;
- Temperature compensation of the analog conditioning chain;
- An alarm notification is send to the BeanGateway® if the internal temperature is abnormally high;

When you plug the BeanDevice® on an external power supply, the power supply status is automatically detected.



If your primary cell charge level is under 5%, it is highly recommended to recharge your battery. Your BeanDevice® from SmartSensor product lines integrates a battery charger.

### 8.2.3.1 BeanDevice® Power Mode status



For further information about Power mode management, please read the technical note TN\_RF\_010: "BeanDevice® Power management"

Power Supply Diagnostic

Temperature :	19,125	°C
Power supply :	Bat	
Power mode :	down	
Battery voltage :	4,060	V
Battery level :	Good	
DiagDate :	21/03/2016 11:56:53	

BLUE LED: The BeanDevice® is power off

Power Supply Diagnostic

Temperature :	19,750	°C
Power supply :	Bat	
Power mode :	sleep with list	
Battery voltage :	4,065	V
Battery level :	Good	
DiagDate :	21/03/2016 11:59:36	

GREEN LED: The BeanDevice® is in sleeping with network Listening power mode

Sleeping with network listening power mode is displayed



Power Supply Diagnostic

Temperature : 16,875 °C

Power supply : Bat

Power mode : sleep mode 

Battery voltage : 4,065 V

Battery level : Good 

DiagDate : 21/03/2016 12:01:36

**GREEN LED:** The BeanDevice® is in active sleeping power mode

Sleeping power mode is displayed

Power Supply Diagnostic

Temperature : 18,750 °C

Power supply : Bat

Power mode : active 

Battery voltage : 4,060 V

Battery level : Good 

DiagDate : 21/03/2016 11:58:36

**RED or YELLOW LED:** The BeanDevice® is in active power mode

Active mode is displayed

### 8.2.4 Frame: System

System

Diagnostic cycle : 00:00:50 *ddd, hh:mm:ss*

Tx power : +18 dBm *dBm*

Listening ratio : 5 00:00:05

Displays diagnostic Cycle in seconds (battery charge status, internal temperature, LQI, PER...).

Displays Radio TX Power in dBm (antenna power is not included)

### 8.2.5 Frame: BeanDevice®


BeanDevice

Platform : AN 4-20 mA

**BeanDevice®  
Platform model**



### 8.2.6 Frame: Product Version



**V (version)** related to a major modification of the embedded software.


**R (Release)** related to a minor modification of the embedded software



*These ID versions should be transmitted to our technical support center when you encountered a material or software dysfunction.*

### 8.2.7 Frame: Actual Data Acquisition mode


This frame displays all the information returned by the BeanDevice® on its actual data acquisition mode:




### 8.2.8 Frame: Battery/Primary Cell status

In this frame, information on battery/primary cell status is displayed.

The BeanDevice® performs frequently a battery diagnostic on the BeanDevice®. An alarm notification is transmitted automatically to the BeanScope® if a battery failure is detected on the BeanDevice®.



If any battery status information is displayed (ex: the BeanDevice® is not connected), status led is white.

When LEDs are green a normal state is indicated. During a malfunction, the LEDs turns red.


Here are the details:

Led definition	Green Led signification	Red led signification
Disable Discharge	Battery discharge activated	Battery discharge deactivated
Disable Charge	Battery charge activated	Battery charge deactivated
Over current during battery discharge	No over current during battery discharge	Over current during battery discharge detected
Over current during battery charge	No over current during battery charge	Over current during battery charge detected
Overvoltage	Any presence of battery overvoltage	Battery over voltage detected on the battery
Under voltage	Any presence of battery under voltage	Battery under voltage detected on the battery




### 8.3 BEANDEVICE® CONFIGURATION

Select the BeanDevice® which must be configured



The screenshot shows the BeanScope software interface. On the left, a tree view lists several devices with their MAC IDs. One device is selected. The main area displays the 'BeanDevice System Profile' and 'BeanDevice' status. A 'Data Acq. config.' dialog box is open, showing settings for 'Data Acq. mode', 'Data Acq. cycle', 'Sampling Rate', and 'Data Acq. duration'. The 'Data acquisition mode options' section includes radio buttons for 'Tx Only', 'Log Only', 'Tx & Log', and 'SA'. The 'Streaming/Streaming Packet options' section includes radio buttons for 'Continuous Monitoring', 'Burst', and 'One Shot'.




The screenshot shows the 'Data Acq. config.' dialog box. It has tabs for 'Data Acq. config.', 'DataLogger', 'System config.', and 'Power mode management'. The 'DataLogger status' section shows 'DataLogger status: Ready', 'Download progress: NA', and 'Download status: NA'. The 'DataLogger manager' section has 'Stop' and 'Erase' buttons. The 'Download manager' section has 'Download', 'Download then erase', and 'Cancel' buttons, along with a 'Switch to commissioning, download then erase' button. The 'Acquisition information' section is partially visible at the bottom.



This frame is composed of several Tabs and includes BeanDevice® OTAC (Over the Air Configuration) Parameters:

- ✓ *Custom display*
- ✓ *Notes*
- ✓ *Data acquisition configuration*
- ✓ *Datalogger*
- ✓ *System configuration*
- ✓ *Power Mode management*

### 8.3.1 Tab: Custom Display



The screenshot shows a software window titled "Custom display" with several tabs: "Notes", "Data Acq. config.", "DataLogger", "System config.", and "Pc". The "Custom display" tab is active. It contains four input fields: "Type" with value "PLATFORM\_TYPE", "Reference" with value "PLATFORM\_REF", "Label" with value "MAC\_ID : 0x 0015E", and "Log folder" with value "Folder E560". A "Validate" button is located below the "Log folder" field.

Parameter	Description
Type	You can enter here the type of BeanDevice® you want to use
Reference	You can assign an internal reference to the BeanDevice® you have purchased.




**Label**

You can assign any sort of Label to your BeanDevice®. Therefore, the user can easily associate the BeanDevice® with its equipment (example: Room\_N521\_Second\_Floor)

Click on "**Validate**" if you want to validate your configuration.

### 8.3.2 Tab: Notes




This field contains your notes concerning the BeanDevice®. To change this field, enter your text and click on « **Validate** » button. To back up your text, press the icon 

**Example:** Machine failure n°XX, requested intervention.



### 8.3.3 Tab : Data Acquisition configuration



Parameter	Different values	Description
Data Acquisition mode	<b>Low duty cycle Data Acquisition (LDCDA)</b>	Low duty cycle data acquisition is adapted for static measurement (tilt, pressure, temperature) requiring a low power consumption on your BeanDevice®. The duty cycle can be configured between 1 data acquisition & transmission per second to 1 data acquisition & transmission per day.
	<b>Survey</b>	Survey mode is a mix between the LDCDA mode and Alarm mode. A data acquisition is transmitted <ul style="list-style-type: none"> <li>Whenever an alarm threshold (fixed by the user) is reached (4 alarm threshold levels High/Low).</li> <li>A transmission cycle is reached, the transmission cycle is configurable through the BeanScape® 1s to 24h ;</li> </ul>
	<b>Streaming Packet</b>	Streaming packet is more suitable for users requiring a high data sampling rate (maximum 5 KHz). In order to achieve these performances, data sampling are transmitted by packet;
Data acquisition Cycle	Select the Data acquisition cycle between 1s and 24hours. The format is: Day : Hour : Minute :Second	




Sampling rate	<p>Select the sampling rate of your BeanDevice® between 1 sample per second and 5000 Samples per second maximum. The resolution is 1 sample per second.</p> <p>If Datalogger is selected, the maximum sampling rate is 2000 samples per second.</p> <p>This field is available in streaming packet, and math mode</p> <p>Choose carefully the Sampling rate value:</p> <ul style="list-style-type: none"> <li>✓ The PER (Packet Error Rate) can increase if the Sampling rate is high on your BeanDevice®. For further information, read the technical note <a href="#">TN RF 003-“Wireless Network capacity”</a></li> <li>✓ Power consumption increases with the sampling rate of your BeanDevice®</li> </ul>
Data acquisition duration	<p>Data acquisition duration in streaming packet, and math mode.</p> <p>The format is Day: Hour: Minute: Second</p> <p>The Data acquisition duration value can be higher than Data acquisition cycle.</p>
Options	<p><b>Tx only:</b> The BeanDevice® transmits the data acquisition without Datalogging</p> <p><b>Log only:</b> The BeanDevice® logs the data acquisition without wireless transmission</p> <p><b>Tx &amp; Log:</b> The BeanDevice® transmits and logs the data acquisition;</p> <p><b>SA: Standalone:</b> The BeanDevice® logs the data acquisition without wireless transmission. The BeanDevice stores all the measurements on its embedded Datalogger. Thus, a direct connection with the BeanGateway® is not needed.</p>



For further information about the Datalogger, please read the technical note [TN RF 007 – “BeanDevice® Datalogger User Guide ”](#)

All your modifications are displayed on “**Current data acquisition mode**” frame:





**Current data acquisition mode**

Data Acq. mode : **LowDutyCycle**

Data Acq. cycle : **00:01:00** *ddd,hh:mm:ss*

Sampling rate : **NA** *Hz*

Data Acq. duration : **NA** *ddd,hh:mm:ss*

Tx  Log




For further information, please read to the technical note [TN\\_RF\\_008 – “Data acquisition modes available on the BeanDevice®”](#)



### 8.3.4 Tab: Datalogger




For further information about Datalogger, please read the technical note *TN\_RF\_007* :  
"BeanDevice® Datalogger User Guide®".



The Logger tag is composed of five different fields:

- **Datalogger Status**
- **Datalogger manager**
- **Download manager**
- **Acquisition information**
- **Datalogger memory configuration**

#### 8.3.4.1 Datalogger status




- **Datalogger status:** Displays logger's status, four statuses are available:
  - **Ready:** the Datalogger is ready to register data
  - **NotInit:** the Datalogger is not initialized;
  - **Active logs only:** Data acquisition is logged only;
  - **Active Tx and Log:** Data acquisition is logged & transmitted by Radio;




- **Stopped:** Datalogger is stopped;
- **Download process:** Displays the download process 0 to 100%. If 100%, all the data logs are successfully downloaded on your PC.
- **Download status:** Displays the download status, two types of status are available:
  - **Processing:** Data logs download is under process;
  - **Completed:** Data Logs are completely downloaded on your PC;

#### 8.3.4.2 Logger manager



- **Stop:** Stops Data Logging process
- **Erase:** Stops & Erases all the logs on flash memory


#### 8.3.4.3 Download manager



- **Download:** Starts to download all the logs on the flash memory
- **Download then erase:** downloads all the logs and the erase them.
- **Cancel:** Stops the download process
- **Switch to commissioning, download then erase.**



### 8.3.5 Tab : System config.




Parameter	Description
<b>Diagnostic cycle</b>	You can set the BeanDevice® diagnostic cycle (Battery status, LQI, PER ...). The Diagnostic cycle is modulo the data acquisition cycle. <i>Ex:</i> If you try to set the diagnostic cycle at 10s while the data acquisition cycle is set at 20s, the diagnostic cycle will be adjusted to 10s ;
<b>TX Power</b>	BeanDevice® TX Power unit is in dBm, it represents the power ratio in decibels (dB) of the measured power referenced to one milliwatt (mW). The antenna radio power is not included. If the BeanDevice® PER is high or the LQI is too low, try to increase the transmission power.



The following flow chart shows the effect of a higher TX power:





*If you fix the TX power at its minimum value (-7dBm), and the wireless range is more than 5m, you will lose the radio signal. To find a configuration with a maximum RF: by pressing the Network Context button, you can reset to factory settings (default RF power is fixed at its maximum: 18 dBm)*



*Some recommendations:*

- *If you fix the TX power at its minimum value (-7dBm): you will lose the radio link between your BeanGateway® and the BeanDevice®, if the wireless range is more than 5m,*
- *By pressing the Network push button for more than 2s, you can reset to factory settings (default RF power is fixed at its maximum: 18 dBm).*



*How to convert dBm to mW*

*Zero dBm equals one milliwatt. A 3dB increase represents roughly doubling the power, which means that 3 dBm equals roughly 2 mW. For a 3 dB decrease, the power is reduced by about one half, making -3 dBm equal to about 0.5 milliwatt. To express an arbitrary power P as x dBm, or go in the other direction, the following equations may be used:*



$$x = 10 \log_{10}(1000P)_{or}, x = 10 \log_{10} P + 30$$

and

$$P = 10^{(x/10)}/1000_{or}, P = 10^{(x-30)/10}$$

where  $P$  is the power in  $W$  and  $x$  is the power ratio in  $dBm$ .



**Inside a building, the maximum authorized power is +12 dBm (antenna power included). It is highly recommended to follow the R&TTE guidelines. For more information please visit <http://www.etsi.org>. It is your responsibility to carefully observe the R&TTE guidelines.**

### 8.3.6 Tab : Power mode management

---



**For further information about Power mode management, please read the technical note TN\_RF\_010: "BeanDevice® Power management"**

This Tab is composed of three frames:

- ✓ **Sleep mode configuration:** Configure the Power mode on your BeanDevice®
- ✓ **Listening Mode Status:** Describes the status of an OTAC (Over-the-air-Configuration)
- ✓ **Sleep mode with listening config. :** Configuration settings for Sleep mode with network listening






Figure 19 : Power mode management

Parameter	Description
<b>Sleep mode configuration</b>	<p><b>Active:</b> Sleeping mode is disabled. The BeanDevice® operates in Active power mode.</p> <p><b>Sleep:</b> Sleeping mode is enabled</p> <p><b>Sleep with nwk listening:</b> Sleep with network listening mode is enabled.</p> <p><b>Ratio:</b> Fix the Ratio of the listening cycle depending on the data acquisition low duty cycle.</p> <p><b>Example :</b> If the data acquisition is 30 seconds, the Listening cycle will be 150 seconds.</p>
<b>Listening mode status</b>	<p><b>Ratio:</b> displays the latest Ratio value</p> <p><b>Waiting:</b> This led is <b>green</b> if an OTAC (Over-the-Air configuration) frame is pending for a transmission to the BeanDevice®</p> <p><b>Sent:</b> This led is <b>green</b> if an OTAC (Over-the-Air configuration) frame is transmitted to the BeanDevice®.</p> <p><b>Deleted:</b> This led is <b>red</b> if a pending OTAC (Over-the-Air configuration) is deleted</p>
<b>Sleep mode with listening config</b>	By clicking on “validate”, the pending OTAC frame is deleted





*"Rethinking sensing technology"*

Document version:2.2

Document Type : User Manual

BeanDevice® User Manual –  
ProcessSensor product lines




*Please consider the environment before printing this document.*

Page : 84 / 126

## 8.4 SENSORS CONFIGURATION

The screen « *Sensor profile* » consists of three parts:

- 1 **General information on the measurement channel;**
- 2 **Measurement channel configuration;**
- 3 **A graph which displays in real-time sensor signals during data acquisition;**




The screenshot displays the BeanScape software interface. On the left is a tree view of sensor channels. The main area is titled 'Sensor profile' and is divided into three sections: 1. 'General information' (Type: SENSOR\_TYPE, Excitation: 0.000, Ref: 2, Label: Ch\_mA\_2, Technology: NI 4-20 mA, State: On). 2. 'Configuration' (Ratio: 1, Offset: 0, Unit: mA, Type: SENSOR\_TYPE, Ref: SENSOR\_REF, Label: Ch\_mA\_2). 3. 'Measurement data' (Value: 0.0011, Date: 21/03/2016 17:37:43). Below the configuration is a real-time graph showing a signal over time, with a blue circle '3' highlighting the graph area. The graph title is 'Measure -0.0011 -mA' and the mode is 'Mode LowDutyCycle'. The x-axis is 'Time' and the y-axis is 'Value'.



### 8.4.1 Sensor profile

#### 8.4.1.1 Frame : General information



**Sensor Type**

**Sensor Reference**

**Sensor label displayed on the BeanScope®**

**BeanDevice® technology**

**Sensor ON/OFF Button: enable/disable the sensor channel**

**Sensor excitation voltage**

**Pre-processing time before the sensor excitation**

*Sensor profile*  
General information

Type : **SENSOR\_TYPE**      Excitation : **20,000** V


Ref : **0**      Pre-proc. : **40** ms

Label : **Ch\_mA\_0**

Technology : **AN 4-20 mA**

State : **On**

#### 8.4.1.2 Frame: Measurement data



**Measurement data value**

**Date and time of the latest measurement**

Measurement data

Value **-271,15**      Date **10/10/2010 01:02:27**

By default, sensor unit format is

- ✓ BeanDevice® AN-V : V
- ✓ BeanDevice® AN-mV : mV
- ✓ BeanDevice® AN-420 : mA



#### 8.4.2 Sensor configuration & calibration

This frame contains a set of 5 tabs:

Custom Display

- Allows the end user to customzie the sensor

Notes

- Contains notes relating to the BeanDevice® sensor

Configuration

- Sensor configuration interface. The user can configure the alarm thresholds related to the sensor
- Depending on the BeanDevice® version which is used, other configuration parameters are available

Measurement conditioning  
& calibration


- Sensor or measurement channel calibration

Log configuration

- Logs configuration on the BeanScope®

##### 8.4.2.1 Tab: Custom display

These parameters allow the user to customize his sensor:



Custom display | Notes | Configuration | Measurement conditioning calibration | Log config.

Ratio :       Offset :

Unit :       Type :

Ref :       Label :

- ✓ **Type**: Describe the sensor type (ex: load cell, pressure, Strain gage +/- 2 Mv/v, LVDT,.... )
- ✓ **Unit**: customer sensor unit (bar, °C, l/h....)
- ✓ **Ratio** : Sensor Ratio coefficient (RAT);
- ✓ **Offset** : Sensor Offset Coefficient (OFF);
- ✓ **Label**: Give a name to your sensor. (ex : Sensor on StatorMachine 1, sensor in Room 2 Floor 3)



**Measurement conversion formula:**

$$\text{Converted Measurement} = \text{Measurement} \times \text{RAT} + \text{OFF}$$

**Example with a temperature sensor:** By default the temperature unit is in degree Celsius. The user wants to convert the unit of his temperature sensor in degree Fahrenheit.


$$\text{Converted Measurement}[^{\circ}\text{F}] = \text{Measurement}[^{\circ}\text{C}] \times \text{RAT} + \text{OFF}$$

With **RAT** = 1.8 and **OFF** = 32

**Conversion assistant**

To avoid conversion error, a conversion assistant is available to help you to setup quickly your measurement channel of your BeanDevice®.


Click on conversion assistant from the tab "Custom display", a window will open allowing you to do a linear conversion.




On the left column, the user can enter the non-converted measurement data. On the right column, the user can enter the converted measurement values with the desired unit.

The ratio and offset values are calculated automatically by the conversion assistant.





#### 8.4.2.2 Tab : Notes



This field contains notes relating to the BeanDevice® sensor. To change this field, enter a value or free text and click the “Validate” button.


A new window opens; accept your modifications by clicking on “OK”.



To backup your text click on the icon “Backup your Database”



8.4.2.3 Tab: Configuration




Parameter	Description
Alarm threshold	<p>Threshold high values (H1, H2) and low values (L1,L2) can be configured. In alarm mode, when a higher low threshold value is reached, an alarm notification is transmitted to the BeanGateway;</p> <ul style="list-style-type: none"> <li>✓ If the sensor value is higher than H1/H2, an alarm notification is send to the BeanGateway/BeanScape;</li> <li>✓ If the sensor value is lower than L1/L2, an alarm notification is send to the BeanGateway/BeanScape;</li> </ul> <p>Threshold values must be organized in this manner: H2&gt;= H1 &gt; L1&gt;=L2</p>
Sensor Pre-processing time configuration	Preprocessing time before the sensor excitation can be configured.

8.4.2.4 Tab : Sensor & Analog conditioning calibration

These coefficients are used to calibrate the external sensors & Light sensor





The BeanScape® provides a calibration interface for each measurement channel:

- **Ratio** : multiplier coefficient
- **Offset**: adder/subtracted coefficient . its unit is the sensor unit.

$$\text{Calibrated\_value} = (\text{Ratio} \times \text{Non\_Calibrated\_Value}) + \text{Offset}$$

Enter the calibration coefficients and then click on Validate.



*The calibrations coefficients are saved on the BeanDevice® flash memory and are conserved during the lifetime of your product.*




***WARNING: These calibration coefficients should be accessible to an advanced user. A wrong calibration will result in false measurements.***



8.4.2.5 Tab : Log configuration

*This tab should not be confused with the Datalogger function available on the BeanDevice®:*



By default, Log file name is built with the measurement channel & BeanDevice® MAC Address:  
< Sensor Channel Number > <MAC\_ID>

- ✓ **Log enabled:** If checked, Log is enabled on the BeanScape®
- ✓ **Log filename auto.:** If checked, Log file name is named automatically

Click on **validate** in order to validate all your modifications.

For users who want to rename the log file, two solutions are provided:

**Solution 1**


**Add automatically the channel "Label" in your log file name:**  
**<Label><Sensor channel Number> <MAC\_ID>**

**Solution 2**

**The log file name can be fully customized:**  
**Uncheck the case « Log filename auto" and add your own label**




### 8.4.3 Graphical display



The chart is composed of two parts:

- **Part 1:** This is a preview window, allowing you to observe sensors acquisitions;
- **Part 2:** A strip on the side composed of different frames allows customizing the graph;

The graph has two axes:




**Axe-X:** Timeline

**Axes-Y:** received sensor acquisitions

The BeanDevice® data acquisition mode and the last data acquisition can be visualized directly from the graph.





### 8.4.3.1 Frame: Display



### 8.4.3.2 Frame: Symbols

From this frame you can select the display mode of action of the chart. Three types of symbols are available:




**Circle:** Brings up a point on each bar graph

**Square:** brings up a square on each measure of the graph


**None:** No logs is displayed on the graph




No symbol activated



Square symbol activated



Circle symbol activated



### 8.4.3.3 Frame : Scale

From this frame, the scaling of the graphics can be customized to suit your needs.



#### Checkbox "Zoom X and Y Zoom"

These boxes are useful for performing a graph zoom from the mouse wheel, there are four cases:

- **Case 1**: Case "Zoom X " ticked. The graph zoom will only affect the X axis.
- **Case 2**: Case "Zoom Y" ticked. The graph zoom will only affect the Y axis.
- **Case 3**: Case "Zoom XY " ticked." Zoom will affect both X and Y axes
- **Case 4**: Case "Zoom X ", "Zoom XY " and "Zoom Y " not ticked. The zoom function from the mouse wheel is disabled.

## 8.5 DATALOGGER CONFIGURATION

---




Please read the technical note [TN RF 007 – "BeanDevice® Datalogger User Guide"](#)



## 8.6 LOG FILE ORGANIZATION

### 8.6.1 Log File System Overview



### 8.6.2 Log file directory

By default, the Log file directory is: **C:\log\_beanscape**



*The following procedure applies only for advanced users*


Click on the tab Tools then Options to configure advanced settings in BeanScape®:





This window lets you configure the logs, and the data cache.

- You will see the following window :



- Clicking the button  reverts back to its original configuration.





### 8.6.3 Log Folder

By Default log files linked to the **BeanDevice®** are stored in the log folder (located in C:/log\_beanscape directory):

“Folder MAC\_ID”

Only the last 4 Char of BeanDevice® MAC ID are displayed.


User can change log folder name by clicking on “Custom display” tab located on the **BeanDevice®** profile:




Enter your own log folder name, then click on validate.

The following example shows the log folder changed to “Factory2”:





#### 8.6.4 Log file size configuration



- ✓ **LOG directory:** Enter here the path/folder where you would want to save the LOG files.
- ✓ **Main log filename:** Here you may enter the desired name in order to save the LOG file.
- ✓ **Main log max. size (KB):** Maximum file size in Kilobytes (KB) for your principal LOG file
- ✓ **Sensor Log Enabled:** Check this box if you want to enable the sensor(s) data acquisition in your LOG file
- ✓ **Sensor log max. size (KB) :** Maximum size in Kilobytes (KB) of sensor log files (**except** for streaming packet data acquisition mode)
- ✓ **Network log info. enabled :** Check this box if you want to enable network information in your LOG file
- ✓ **Network info log max. size (KB) :** Maximum size in Kilobytes for your network information LOG file
- ✓ **Streaming log max. size :** Maximum size in Kilobytes (KB) of sensor log files (**only** for streaming packet data acquisition mode)



### 8.6.5 Log file generation

By default, 1 log file is linked to 1 sensor channel. The user can select a log file linked to all the sensor channels present on the BeanDevice®.

Log file generation

All sensor channels in one file

Separated

### 8.6.6 Cache Data Configuration (for Graph)

Data Cache Configuration

Max. points :	40000
Max. packets :	6
Max. diagnostics :	1000
Max. alarms :	25
Gps coord. max. number :	100
Max. streaming points :	10000
Max. BGW Module status nbr. :	100
Syst. Maint. Status max nbr :	500

- ✓ **Maximum number of points:** Set here the maximum number of points displayed on the BeanScape® graph
- ✓ **Maximum number of packets:** Set here the maximum number of packets displayed on the BeanScape® graph
- ✓ **Max number of diagnostics:** Set here the maximum number of diagnostics displayed on the BeanScape® graph
- ✓ **Max number of alarms:** Set here the maximum number of alarms displayed on the BeanScape® graph
- ✓ **Maximum number of GPS coordinates:** Set here the maximum number of GPS information;
- ✓ **Maximum streaming points:** Set here the maximum number of points displayed in Streaming Packet on the BeanScape® graph



**Please note that the values backed up by the BeanScape® may affect the memory capacity of your computer depending upon the size of every file.**




## 8.6.7 Log file related to data acquisition

### 8.6.7.1 Log filename root

For each sensor channel a log file is automatically created by the BeanScope®.

The user can easily change the log file root:




The screenshot shows the BeanScope software interface. On the left, a tree view lists sensor channels. A callout bubble points to a selected channel with the text "Select the sensor channel". On the right, the "Log Config" tab is active, showing configuration options for logging. A second callout bubble points to this tab with the text "Click on « Log. Config » Tab". The main display area shows a graph titled "Mode Commissioning" with a y-axis labeled "Observed values" ranging from 0.0000 to 10.0000 and an x-axis labeled "Time" with markers for 00 mars 22, 00.00 mars 23, and 00.00 mars 24. The graph shows a single data point at "Measure 0 mA".



***This tab should not be confused with the Datalogger feature available on the BeanDevice®.***

For further information, please refer to the section [Log configuration](#).





By default, Log file name is built with the measurement channel & **BeanDevice®** MAC Address:

< Sensor Channel Number > <MAC\_ID>

- ✓ **Log enabled:** If checked, Log is enabled on the BeanScape®
- ✓ **Log filename auto.:** If checked, Log file name is named automatically

Click on **validate** in order to validate all your modifications.

For users who want to rename the log file, two solutions are provided:

<b>Solution 1</b>	<p>Add automatically the channel "Label" in your log file name:                  &lt;Label&gt;&lt;Sensor channel Number&gt; &lt;MAC_ID&gt;</p>
<b>Solution 2</b>	<p>The log file name can be fully customized:                  Uncheck the case « Log filename auto" and add your own label</p>

### 8.6.7.2 Specific case: log filename creation in "Streaming Packet" mode

In Streaming packet mode, log filename is built as follow:

**Stream\_Sensor\_channel\_MAC\_ID\_DATE\_partXXX**

- ✓ **Sensor channel = Sensor channel**
- ✓ **MAC\_ID: BeanDevice® MAC ID**
- ✓ **DATE: date when the streaming mode starts**
- ✓ **partXXX : Log file sequence number, part000 corresponds to the first log file**

**Example:**

Stream\_0 x 0\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part000

Stream\_0 x 2\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part001



Stream\_0 x 1\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part001

### 8.6.7.3 Log file analysis

```
Stream_0 x 0_0 x 00158D000004C79F_02-11-2011_17.55.05_part000 - Bloc-notes
Fichier Editer Format Affichage ?
-----
Beansensor AX-3D
Mac Id : 00158D000004C79F
Network Id : 0003
Pan Id : 0146
Sensor Id : 0
Sensor Label : ch_X
Ratio : 1
Offset : 0
Unit : g
Date : 02/11/2011 17:55:05
Measure cycle : 10
Measure Duration : 0
Sampling Frequency : 1000
-----
Measure Index;Measure value
0:-0,0041
1:-0,0035
2:-0,0035
3:-0,0033
4:-0,0029
5:-0,0038
6:-0,0063
7:-0,0023
8:-0,0038
9:-0,0038
10:-0,0038
11:-0,0026
12:-0,0026
13:-0,005
14:-0,005
15:-0,0026
16:-0,0029
17:-0,0035
18:-0,0014
19:-0,0014
20:-0,0038
21:-0,0035
22:-0,0035
23:-0,0011
24:-0,0026
25:-0,0032
26:-0,0038
27:-0,0035
28:-0,0029
29:-0,0029
30:-0,0035
```

The date which is displayed in the log file corresponds to the date when the streaming mode starts.

**Measure index** allows the user to use a timestamp, the time value between the Index N and N+1 corresponds to the period rate.

**Example:** Data acquisition starts at 17h55min05s

A data acquisition with a measurement index of 30 (value -0,0035) corresponds to a time 17h55min05s30ms.

## 8.6.8 Log file organization in " Streaming Packet" mode

### 8.6.8.1 Log file naming format

In Streaming packet mode, log file is built with a different format:

Stream\_Sensor\_channel\_MAC\_ID\_DATE\_partXXX

- ✓ **Sensor channel = Sensor channel**
- ✓ **MAC\_ID: BeanDevice® MAC ID**
- ✓ **DATE: date when the streaming mode starts**



✓ *partXXX* : Log file sequence number, *part000* corresponds to the first log file

**Example:**

Stream\_0 x 0\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part000


Stream\_0 x 2\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part001

Stream\_0 x 1\_0 x 00158D000004C79F\_02-11-2011\_17.55.05\_part001

8.6.8.2 Log file analysis

Log file related to wireless network diagnostic provides the following informations:

- **Date** : diagnostic date
- **LQI TX**: Link quality indicator on the BeanDevice® side
- **LQI RX**: Link quality indicator on the BeanGateway® side
- **Local PER Tx**: Local Packet Error Rate on the BeanDevice® side
- **Local PER Rx**: Local Packet Error Rate on the BeanGateway® side
- **Global PER**: N.A.
- **Battery voltage**: internal battery voltage
- **Battery level**: battery level of charge
- **Internal temperature**: Local temperature of the BeanDevice®



```
00158D00000E03E5_WirelessNetwkInfo - Bloc-notes
Fichier Edition Format Affichage ?
-----
BeanComponent Wireless Network Information
Date : 5/31/2014 6:31:17 PM
PAN_ID : 2427
MAC_ID : 00158D00000E03E5
-----

Date ; LQI TX ; LQI RX ; Local PER Tx ; Local PER Rx ; Global PER ; Battery Voltage ; Battery Level ; Internal Temp
5/31/2014 6:31:16 PM;192;NA;0.00;NA;0.00;4.089;100.00;21.000;N;N;N;N;N; NA
5/31/2014 6:31:17 PM;174;NA;0.00;NA;0.00;4.089;100.00;21.125;N;N;N;N;N; NA
5/31/2014 6:31:18 PM;162;NA;0.00;NA;0.00;4.089;100.00;21.125;N;N;N;N;N; NA
5/31/2014 6:31:19 PM;150;NA;0.00;NA;0.00;4.089;100.00;21.000;N;N;N;N;N; NA
5/31/2014 6:31:20 PM;168;NA;0.00;NA;0.00;4.089;100.00;21.125;N;N;N;N;N; NA
5/31/2014 6:31:21 PM;162;NA;0.00;NA;0.00;4.089;100.00;21.125;N;N;N;N;N; NA
5/31/2014 6:31:22 PM;168;NA;0.00;NA;0.00;4.089;100.00;21.125;N;N;N;N;N; NA
```



If the BeanDevice® is configured with the streaming packet data acquisition mode, the following diagnostic information are not refreshed:

- **Battery voltage**
- **Battery level**
- **Internal temperature**

```

Fichier Edition Format Attelage ?
-----
BeanComponent Wireless Network Information
Date : 5/15/2014 4:50:44 PM
PAN_ID : 31BB
MAC_ID : 00158D0000AD564
-----


Date ; LQI Tx ; LQI Rx ; Local PER Tx ; Local PER RX ; Global PER ; Battery Voltage ; Battery Level ; Internal Temperature

5/15/2014 4:50:43 PM;174;NA;0.00;NA;0.00;4.094;0.00;24.625;N;N;N;N;N; NA
15/05/2014 16:50:45.000000;168;;0.00;;;;
15/05/2014 16:50:45.150000;180;;0.00;;;;
15/05/2014 16:50:45.300000;162;;0.00;;;;
15/05/2014 16:50:45.450000;168;;0.00;;;;
15/05/2014 16:50:45.600000;174;;0.00;;;;
15/05/2014 16:50:45.750000;186;;0.00;;;;
15/05/2014 16:50:45.900000;138;;0.00;;;;
15/05/2014 16:50:46.050000;144;;0.00;;;;
15/05/2014 16:50:46.200000;150;;0.00;;;;


```

### 8.6.8.3 How to open a measurement file with excel

#### Step 1 : Open Excel




#### Step 2: Go on « Data » Tab, then select “From Text”




#### Step 3 : Choose your log file






**Step 4 :** Text import wizard will open, select « Delimited » for Characters such as commas or tabs separate each field.

On “Start import at row” field: Select the number of lines that you want to suppress from the header:



Select semicolon






*"Rethinking sensing technology"*

Document version:2.2


Document Type : User Manual

BeanDevice® User Manual –  
ProcessSensor product lines


## Select Text



## Click on OK



## Click on format cells:



[See "Exporting a log file to Excel" Youtube video](#)



*Please consider the environment before printing this document.*

Page : 108 / 126

## 9. BEANDEVICE® MAINTENANCE & SUPERVISION (FOR EXPERIENCED USER)

This section allows to an experienced user to configure correctly the Wireless Sensor Networks.

### 9.1 HOW TO OPTIMIZE THE BATTERY AUTONOMY ON YOUR BEANDEVICE®

The battery autonomy depends on several parameters:

- ✓ The environment where the BeanDevice® is deployed
- ✓ Data acquisition mode which is configured

The table below presents the BeanDevice® current consumption during radio TX or during Sleep mode:

<i>BeanDevice® version</i>	<i>Current consumption during radio TX at 25°C, powered by a battery of 3,6V</i>	<i>Current consumption in sleep mode at 25°C, powered by a battery of 3,6V</i>
BeanDevice® AN-mV	60-61 mA (external sensor power supply not included)	< 40 uA
BeanDevice® AN-420	60-61 mA (external sensor power supply not included)	< 40 uA
BeanDevice® AN-V	60-61 mA (external sensor power supply not included)	< 40 uA



For further information, please read the technical note [TN\\_RF\\_002 - Current consumption in active & sleeping mode](#)



The following table gives you a list of recommendations in order to extend the battery autonomy of your BeanDevice®:


Influence factors on battery autonomy	Observations	Recommendations
<i>Sleep power mode on the BeanDevice®</i>	The BeanDevice® can be configured with sleep mode from the BeanScape® interface	By activating sleep power mode on your BeanDevice®, you will dramatically decrease battery autonomy of your BeanDevice®. By activating sleep mode, the BeanDevice® current consumption can decrease from 30 mA to 10-45 micro-amperes.  <i>For further information, please read the technical note <a href="#">TN_RF_010 – « BeanDevice® Power Management »</a></i>
<i>Sampling rate in streaming mode</i>	The higher your sample rate, the higher the RF transmissions are more consistent and your consumption will grow.	Choose the right sampling rate on your BeanScape® interface.
<i>TX Power</i>	More your TX power is important more the current consumption of the BeanDevice® is important	If your wireless range is low, try to use a lower TX Power.
<i>Packet Error Rate (PER)</i>	A high packet error rate can cause a higher retransmission data and this increase the current consumption.	Try to replace your BeanDevice® in an area where the radio link is much better (see Link Quality Indicator value).



## 9.2 OVER-THE-AIR CONFIGURATION (OTAC) PARAMETERS BACKED UP ON FLASH

The BeanDevice® integrates an internal flash memory used for backuping OTAC (Over-the-air configuration) configuring parameter backups and restoration.

This memory is organized into several levels:



### 9.2.1 Level 1: End-user OTAC parameters

The following table presents all the defaults configuration parameters:

To restore these defaults parameters, you must perform a **Network context deletion**. The “Network” push button is outside the product.

Parameter	BeanDevice® version		
	AN-420	AN-V	AN-mV
Power Mode	Active	Active	Active
Data Acquisition duty cycle	10s	10s	10s
Acquisition duration time	OK	OK	OK
Sampling rate	OK	OK	OK
Data Acquisition mode	LowDutyCycle	LowDutyCycle	LowDutyCycle
TX Power	+18dBm	+18dBm	+18dBm
Alarms Threshold	H1 :20 H2 :20 S2 :4 S1 :4	H1 :10 H2 :10 S2 :0 S1 :0	H1 :20 H2 :20 S2 :0 S1 :0
Pre-process duration time	30 ms	30 ms	30 ms
Sensor polarity	N.A.	Unipolar	Unipolar



Level 2, 3 & 4 of Configuration parameters are not affected by network context deletion (by hardware or software)



### 9.2.2 Level 2: Sensor calibration parameters

The table below shows the sensor calibration parameters depending on BeanDevice® version:

Parameter	BeanDevice® Version		
	AN-420	AN-V	AN-mV
Sensor gain	OK	OK 2 gains value (unipolar & bipolar)	OK 2 gains value (unipolar & bipolar)
Sensor offset	OK	OK 2 offset value (unipolar & bipolar)	OK 2 offset value (unipolar & bipolar)

### 9.2.3 Level 3: Network maintenance (only for expert in wireless sensor networks)

The table below shows the sensor calibration parameters depending on *BeanDevice®* version:

Parameter	BeanDevice® Model		
	AN-420	AN-V	AN-mV
Software reset counter	OK	OK	OK
Physical reset counter	OK	OK	OK
Threshold value on software reset	OK	OK	OK



### 9.2.4 Level 4: Primary cell/Rechargeable battery calibration

The table below shows Primary cell/Rechargeable battery calibration depending on *BeanDevice®* version:

Parameter	BeanDevice® Model		
	AN-420	AN-V	AN-mV
Battery, primary cell ID	OK	OK	OK
Calibration batterie/pile	OK	OK	OK


## 9.3 NETWORK DIAGNOSTIC FROM YOUR BEANSCAPE® SOFTWARE

The BeanScape® provides network diagnostic information which is described in this chapter.

### 9.3.1 Displaying Network information


1. Launch your BeanScape® application
2. Select your BeanDevice® profile, a new tab "BeanDevice" will appear in your BeanScape® toolbar;
3. Click on this tab, and then click on "View History Network".





Click on the BeanDevice®


Click on your BeanDevice



Click on « Display wireless network Information »



**A new window occurs:**



**9.3.1.1 Packet Error Rate**

**Packet error rate (PER)** is the number packet errors divided by the total number of transferred packet during a studied time interval. PER is a unit less performance measure, often expressed as a percentage number.

PER is only available with IEEE 802.15.4 Network, it represents the ratio of "lost data/data send" between the BeanDevice® and the BeanGateway®.

**9.3.1.2 LQI (Link Quality Indicator)**

LQI (Link Quality Indicator) represents the radio signal quality in your Environment. It is possible that LQI is low due to EMC interference or metal presence in the environment.

**If you encounter such problems, several solutions are proposed to increase your LQI:**

- ✓ Use the Maximum TX Power on your BeanDevice. The maximum TX Power authorized in Europe for indoor application is 12 dBm. For Outdoor application, you are authorized to



extend the TX Power to 18 dBm. You can easily configure the TX Power on your BeanDevice from your BeanScape WSN software supervision.

- ✓ Try to configure your receiver antenna and your transmitter antenna on the same antenna pattern (cf. the Beam with of your antenna)
- ✓ Use a high gain antenna ( in outdoor use only) for a better RF Link Budget
- ✓ Fix your BeanDevice & BeanGateway on a top of a mast or a building.



***For further information, read the application note on "How to extend your wireless range?"***

#### 9.3.1.3 Internal temperature monitoring

An internal temperature sensor is used for onboard & battery temperature monitoring

#### 9.3.1.4 Battery charge monitoring

Battery charge is based on current accumulation. The BeanDevice® integrates a current accumulator circuit which facilitates remaining capacity estimation by tracking the net current flow into and out of the battery. Current flow into the battery increments the current accumulator while current flow out of the battery decrements it.


Voltage measurement corresponds to battery voltage.



### 9.3.2 Scrolling menu « BeanSensor »

The BeanSensor® scrolling menu provides access to additional features: like the multi-graph mode (display of multiple windows on a graph measuring the same screen), deleting graphs displayed and the activation / deactivation of logging measurements.

To access to this scrolling menu, click on the sensor attached to your BeanDevice®. You will then see the BeanSensor® scrolling menu appearing.





By clicking on the scrolling menu « BeanSensor », you can access to the following features :

### 9.3.2.1 Disable/Enable log

All the data received on the BeanScope® are stored in a log file in CSV format.

This feature allows you to enable / disable data logging on your log file.



*For further information about CSV log file, please read the BeanScope® user manual.*



### 9.3.2.2 Buffer reset

This function clears the graphical display concerning recorded measurements of your sensor. The data stored in a log are not affected by this function.

By clicking on « Buffer reset », a second window appears asking you to confirm your choice:


- Yes, you accept to delete the whole measure data of this BeanSensor;
- No, don't delete the whole measure data of this BeanSensor;






### 9.3.2.3 Open the graph in a new window

By clicking on “Open the graph in a new window”, you can open a graph corresponding to your sensor.



You can easily open several graphs in a window.





*The multi-graph mode requires a lot of resources on your computer, it is recommended to install the BeanScope® software on a powerful computer.*



## 10. TROUBLESHOOTING

---

### ■ *Why the Red LED is flashing?*

Each time a packet is lost by the BeanDevice®, Nwk/Activity led will blink in red. Try to decrease the wireless range between the BeanGateway® and the BeanDevice®.

### ■ *Why the BeanDevice® LEDS are not activated?*

If there is no wireless network activity, the led will be inactive. Make sure you have powered your BeanDevice® with a charged battery.

### ■ *What should I do if the radio channel is perturbed?*

Please turn off your BeanDevice®, and then choose an appropriate channel. The channel selection is done from the BeanGateway®.

For further information, please Read BeanGateway User's Manual BeanGateway®.

### ■ *Why the BeanDevice® does not provide the right measurement value?*

- Check if your sensor channel is activated on your BeanScape® interface (ON Position)?;
- Check if your BeanDevice® is powered up;
- Check your LQI quality, if your LQI is under 50-60. You must change your antenna position, or your product position;
- Check your data acquisition mode, maybe you have specified a data acquisition which is too long ;
- If you use a BeanDevice® AN-XX :
  - Check your sensor power supply, maybe you need to increase/decrease your power supply;
  - Check your sensor preprocess time. Maybe your sensor preprocess time is too short ?
  - Check the wiring code of your sensor plug ;

### ■ *Why the BeanDevice® doesn't respond when I try to configure it (Over-the-air-configuration)?*

- ✓ If your BeanDevice® operates in sleep mode, the RF Hardware is also in sleep mode. Therefore an Over-the-air-configuration will not be possible.



- ✓ Check the LQI (Link Quality Indicator) value, if this value is under 80, the over-the-air configuration will not be easy. Try to decrease the wireless range between the BeanDevice® and the BeanGateway®.
- ✓ If your BeanDevice® works in streaming mode, in order to keep a full synchronization of the data acquisition, any over-the-air-configuration is authorized.

■ *Why do I have too much noise on my sensor signal ?*

- ✓ If you use a BeanDevice® AX3D/HI-INC/AX-HD : don't forget to configure the cutoff frequency of your anti-aliasing filter
- ✓ If you use a BeanDevice® AN-mV: use a shielded cable.



## 11. INSTALLATION PROCEDURES

### 11.1 SEALING

The product BeanDevice® comes with an **IP66** rating. So, do not install the BeanDevice® in a marine environment with high turbulence.

If you use the BeanDevice® AN-XX/TSI/TH, do not install the BeanDevice® up front to prevent the accumulation and infiltration of water from the front of the case.

### 11.2 COEXISTENCE WITH OTHERS FREQUENCIES AT 2.4 GHZ

The BeanDevice® is sensitive to noise 2.4GHz (Wi-Fi as a source for example), but many protections are already in place, particularly in the IEEE 802.15.4®.

It should however be careful when installing the product, check all the possibilities of radio channels on the frequency range 2.4-2.5GHz. The operation of the product will be improved.



*For further information, read the application note: [TN RF 011 – “Coexistence of Beanair WSN at 2.4GHz”](#)*

### 11.3 TEMPERATURE & HUMIDITY

The table below shows temperature operating of the different BeanDevice®:

Product Version	Temperature range
BeanDevice® AN-XX	-20 °C to +75 °C
BeanDevice AN-XX Xtender	-40 °C to +85 °C

BeanDevice® products can operate in an area with 90% humidity.

However, the wireless range can be reduced in the presence of water. Avoid mounting the BeanDevice® in an enclosure surrounded by water, or near bushy plants (plants are composed of 90% water), ...



## 11.4 REFLECTIONS, OBSTRUCTIONS AND MULTIPATH

---



*For further information, read the application note: [AN RF 007](#) :“  
Beanair WSN Deployment”*



## 11.5 SHOCK & VIBRATION RESISTANCE

---

Shock resistance on BeanDevice® products are:

<i>BeanDevice® Type</i>	<i>Shock resistance</i>
<i>BeanDevice® AN-XX</i>	10g during 50 ms

Avoid dropping the BeanDevice®. BeanDevice® mechanical mounting on a wall, pole or on a DIN rail must be well performed.

***Do not force connections.***

## 11.1 ANTENNA

---

Check the LQI (Link Quality Indicator) of your BeanDevice® for being sure that your antenna is right oriented.



*For further information, read the application note: [AN RF 007](#) :“  
[Beanair WSN Deployment](#)”*

